

# **InAsSb photovoltaic detector**

P11120-201

High-speed response and high sensitivity in the 5  $\mu$ m spectral band Thermoelectrically cooled infrared detector with no liquid nitrogen required

The P11120-201 is an infrared detector that provides high sensitivity in the 5  $\mu$ m spectral band due to our unique crystal growth technology. The InAsSb photovoltaic detector has a PN junction that ensures high-speed response and high reliability. Typical applications include gas analysis such as CO2, SOx, CO and NOx. Unlike the P11120-901 metal dewar type detector, the P11120-201 is easy to use as it uses a compact package (TO-8) not requiring liquid nitrogen.

#### Features

- High-speed response
- → High sensitivity
- High reliability
- **■** Compact, thermoelectrically cooled TO-8 package
- **■** Environment-friendly due to use of InAsSb
- Suitable for detecting infrared rays emitted from QCL

#### Applications

- Gas analysis
- Radiation thermometers
- Thermal imaging
- Remote sensing
- **→** FTIR
- Spectrophotometry

#### Options (sold separately)

- → Heatsink for two-stage TE-cooled type A3179-01
- **Temperature controller C1103-04**
- **■** Infrared detector module with preamp C4159-07

#### Structure

Parameter	Specification	Unit	
Window material	Sapphire	-	
Package	TO-8	-	
Cooling	Two-stage TE-cooled	-	
Photosensitive area	φ1.0	mm	

#### **Absolute maximum ratings**


Parameter	Symbol	Value	Unit
Thermistor power dissipation	-	0.2	mW
Reverse voltage	VR	0.1	V
Operating temperature	Topr	-40 to +60	°C
Storage temperature	Tsta	-55 to +60	°C

Note: Exceeding the absolute maximum ratings even momentarily may cause a drop in product quality. Always be sure to use the product within the absolute maximum ratings.


# **➡** Electrical and optical characteristics (Td=-30 °C)

Parameter	Symbol	Condition	Min.	Тур.	Max.	Unit
Peak sensitivity wavelength	λр		4.0	4.9	-	μm
Cutoff wavelength	λc		5.6	5.9	-	μm
Photo sensitivity	S	λ=λρ	0.8	1.6	-	A/W
Shunt resistance	Rsh	VR=10 mV	10	13	-	Ω
Detectivity	D*	(λρ, 600, 1)	$3.5 \times 10^{9}$	$5.0 \times 10^{9}$	-	cm·Hz <sup>1/2</sup> /W
Noise equivalent power	NEP	λ=λρ	-	1.8 × 10 <sup>-11</sup>	2.5 × 10 <sup>-11</sup>	W/Hz <sup>1/2</sup>
Rise time	tr	V <sub>R</sub> =0 V, R <sub>L</sub> =50 Ω 0 to 63%	-	0.4	-	μs


# **⇒** Spectral response (D\*)




# Spectral response




#### Dark current vs. reverse voltage



#### **Shunt resistance vs. element temperature**




# **Linearity**




# **➡** Specifications of two-stage TE-cooler (Ta=25 °C)

Parameter	Symbol	Min.	Тур.	Max.	Unit
Allowable current	Ic	-	-	1.0	Α
Allowable voltage	Vc	-	-	0.95	V
Thermistor resistance	Rth	8.1	9.0	9.9	kΩ
Thermistor power dissipation	Pth	-	-	0.2	mW


#### **Current vs. voltage of TE-cooled type**



# **Cooling characteristics of TE-cooled type**




#### Thermistor temperature characteristic




KIRDB0116EA

#### Measurement circuit example



#### Dimensional outline (unit: mm)

 $5.1 \pm 0.2$ 



**HAMAMATSU** PHOTON IS OUR BUSINESS

KIRDA0212EA

### InAsSb photovoltaic detector

P11120-201

#### Related information

www.hamamatsu.com/sp/ssd/doc\_en.html

- Precautions
  - Dislaimer
  - · Metal, ceramic, plastic products
- Technical information
  - · Infrared detectors

Information described in this material is current as of May, 2015.

Product specifications are subject to change without prior notice due to improvements or other reasons. This document has been carefully prepared and the information contained is believed to be accurate. In rare cases, however, there may be inaccuracies such as text errors. Before using these products, always contact us for the delivery specification sheet to check the latest specifications.

The product warranty is valid for one year after delivery and is limited to product repair or replacement for defects discovered and reported to us within that one year period. However, even if within the warranty period we accept absolutely no liability for any loss caused by natural disasters or improper product use. Copying or reprinting the contents described in this material in whole or in part is prohibited without our prior permission.

# MAMATSU

www.hamamatsu.com

HAMAMATSU PHOTONICS K.K., Solid State Division

1126-1 Ichino-cho, Higashi-ku, Hamamatsu City, 435-8558 Japan, Telephone: (81) 53-434-3311, Fax: (81) 53-434-5184
U.S.A.: Hamamatsu Corporation: 360 Foothill Road, Bridgewater, N.J. 08807, U.S.A., Telephone: (1) 908-231-0960, Fax: (1) 908-231-1218
Germany: Hamamatsu Photonics Deutschland GmbH: Arzbergerstr. 10, D-82211 Herrsching am Ammersee, Germany, Telephone: (49) 8152-375-0, Fax: (49) 8152-265-8
France: Hamamatsu Photonics France S.A.R.L.: 19, Rue du Saule Trapu, Parc du Moulin de Massy, 91882 Massy Cedex, France, Telephone: 33-(1) 69 53 71 00, Fax: 33-(1) 69 53 71 10

im, Telephone: (44) 1707-294888, Fax: (44) 1707-325777

United Kingdom: Hamamatsu Photonics UK Limited: 2 Howard Court, 10 Tewin Road, Welvyn Garden City, Hertfordshire AL7 1BW, United Kingdom, Tel North Europe: Hamamatsu Photonics Norden AB: Torshamnsgatan 35 16440 Kista, Sweden, Telephone: (46) 8-509-031-00, Fax: (46) 8-509-031-01 Italy: Hamamatsu Photonics Italia S.r.l.: Strada della Moia, 1 int. 6, 20020 Arese (Milano), Italy, Telephone: (39) 02-93581733, Fax: (39) 02-93581741

China: Hamamatsu Photonics (China) Co., Ltd.: B1201, Jiaming Center, No.27 Dongsanhuan Beilu, Chaoyang District, Beijing 100020, China, Telephone: (86) 10-6586-6006, Fax: (86) 10-6586-2866