



# InAsSb photovoltaic detectors

P13894 series

# High-speed response and high sensitivity in the spectral band up to 11 µm **Infrared detectors**

The P13894 series are photovoltaic type infrared detectors that have achieved high sensitivity in the spectral band up to 11 µm using Hamamatsu unique crystal growth technology and process technology. They are compact and easy to handle.

#### Features

- ➡ High sensitivity
- → High-speed response
- **→** High shunt resistance
- Non-cooled (P13894-011NA/-011MA), compact package

#### Applications

- Gas detection (CH4, CO2, CO, NH3, O3, etc.)
- Radiation thermometers
- Options (sold separately)
- **■** Amplifier for infrared detector

C4159-01

#### Structure

Parameter	P13894-011NA	P13894-011MA	P13894-211MA	Unit	
Window material	None	Ge with AR coating	Ge with AR coating	-	
Package	TO-5	TO-8	-		
Cooling	Non-coo	Two-stage TE-cooled type	-		
Photosensitive area	1 × 1				
Field of view (FOV)	97	113	degrees		

#### Absolute maximum ratings

Parameter	Symbol	Condition	P13894-011NA	P13894-011MA	P13894-211MA	Unit	
Reverse voltage	VR			1		V	
Operating temperature	Topr	No dew condensation*1	-40 to +85	-40 to	°C		
Storage temperature	Tstg	No dew condensation*1	-40 to +85 -40 to +60			°C	
Soldering conditions			260 °C or less, within 10 s				

<sup>\*1:</sup> When there is a temperature difference between a product and the surrounding area in high humidity environment, dew condensation may occur on the product surface. Dew condensation on the product may cause deterioration in characteristics and reliability. Note: Exceeding the absolute maximum ratings even momentarily may cause a drop in product quality. Always be sure to use the product within the absolute maximum ratings.


#### **➡** Electrical and optical characteristics (Ta=25 °C)

Parameter Symbo	Symbol	ool Condition	P13894-011NA		P13894-011MA		P13894-211MA		Unit			
	Syllibol		Min.	Тур.	Max.	Min.	Тур.	Max.	Min.	Тур.	Max.	UIIIL
Chip temperature	Tchip			25			25			-30		°C
Peak sensitivity wavelength	λр		-	5.6	-	-	5.6	-	-	5.6	-	μm
Cutoff wavelength	λс		9.7	11.0	-	9.7	11.0	-	8.9	10.2	-	μm
Photosensitivity	S	λ=λp*2	1.4	2.0	-	1.3	1.9	-	2.8	3.8	-	mA/W
Shunt resistance	Rsh	VR=10 mV	1.5	2.0	-	1.5	2.0	-	7.5	10.0	-	kΩ
Detectivity	D*	(λρ, 1200, 1)	$4.0 \times 10^{7}$	$7.0 \times 10^{7}$	-	$3.8 \times 10^{7}$	$6.5 \times 10^{7}$	-	$1.8 \times 10^8$	$3.2 \times 10^{8}$	-	cm·Hz <sup>1/2</sup> /W
Noise equivalent power	NEP	λ=λρ	-	1.4 × 10 <sup>-9</sup>	$2.5 \times 10^{-9}$	-	$1.5 \times 10^{-9}$	$2.6 \times 10^{-9}$	-	$3.1 \times 10^{-10}$	$5.6 \times 10^{-10}$	W/Hz <sup>1/2</sup>
Terminal capacitance	Ct	VR=0 V, f=1 MHz	-	0.6	-	-	0.6	-	-	0.6	-	pF
Rise time	tr	10 to 90%, no window, λ=1.55 μm	-	3	10	-	3	10	-	3	10	ns


<sup>\*2:</sup> Uniform irradiation on the entire photosensitive area

Note: Uniform irradiation must be applied to the entire photosensitive area during use.


#### Spectral response (D\*)




#### Photosensitivity temperature characteristics (P13894-011MA/-211MA)



#### Spectral transmittance characteristics of window material




#### **Linearity (P13894-011NA)**




KIRDB0630EA

#### Shunt resistance vs. chip temperature




#### - Directivity (P13894-011NA)




#### **►** Specifications of two-stage TE-cooler (Ta=25 °C)

Parameter	Symbol	Min.	Тур.	Max.	Unit
Allowable current	Ic	-	-	1.0	Α
Allowable voltage	Vc	-	-	0.95	V
Thermistor resistance	Rth	8.1	9.0	9.9	ΚΩ
Thermistor allowable dissipation	Pth	-	-	0.2	mW


#### **Current vs. voltage characteristics of TE-cooler**




#### **Cooling characteristics of TE-cooler**



#### **→** Thermistor temperature characteristics





## **►** Measurement circuit example



### Dimensional outline (unit: mm)


#### P13894-011NA









#### P13894-011MA







KIRDA025



#### Related information

www.hamamatsu.com/sp/ssd/doc\_en.html

- Precautions
- · Disclaimer
- · Compound semiconductor photosensors
- Technical information
- · Infrared detectors

Information described in this material is current as of January 2017.

Product specifications are subject to change without prior notice due to improvements or other reasons. This document has been carefully prepared and the information contained is believed to be accurate. In rare cases, however, there may be inaccuracies such as text errors. Before using these products, always contact us for the delivery specification sheet to check the latest specifications.

The product warranty is valid for one year after delivery and is limited to product repair or replacement for defects discovered and reported to us within that one year period. However, even if within the warranty period we accept absolutely no liability for any loss caused by natural disasters or improper product use. Copying or reprinting the contents described in this material in whole or in part is prohibited without our prior permission.

# **HAMAMATSU**

www.hamamatsu.com

HAMAMATSU PHOTONICS K.K., Solid State Division

1126-1 Ichino-cho, Higashi-ku, Hamamatsu City, 435-8558 Japan, Telephone: (81) 53-434-3311, Fax: (81) 53-434-5184

U.S.A.: Hamamatsu Corporation: 360 Foothill Road, Bridgewater, N.J. 08807, U.S.A., Telephone: (1) 908-231-0960, Fax: (1) 908-231-1218

Germany: Hamamatsu Photonics Deutschland GmbH: Arzbergerstr. 10, D-82211 Herrsching am Ammersee, Germany, Telephone: (49) 8152-375-0, Fax: (49) 8152-65-8

France: Hamamatsu Photonics France S.A.R.L.: 19, Rue du Saule Trapu, Parc du Moulin de Massy, 1882 Massy Cedex, France, Telephone: 33-(1) 69 53 71 00, Fax: 33-(1) 69 53 71 00

United Kingdom: Hamamatsu Photonics UK Limited: 2 Howard Court, 10 Tewin Road, Welwyn Garden City, Hertfordshire AL7 1BW, United Kingdom, Telephone: (44) 1707-294888, Fax: (44) 1707-325777

North Europe: Hamamatsu Photonics Norden AB: Torshamnsgatan 35 16440 Kista, Sweden, Telephone: (49) 8-509-031-01

Italy: Hamamatsu Photonics Italia S.r.l.: Strada della Moia, 1 int. 6, 20020 Arese (Milano), Italy, Telephone: (39) 02-93581733, Fax: (39) 02-93581731

China: Hamamatsu Photonics (China) Co., Ltd.: B1201, Jiaming Center, No.27 Dongsanhuan Beilu, Chaoyang District, Beijing 100020, China, Telephone: (86) 10-6586-6006, Fax: (86) 10-6586-2866