## **Magnetic Shield Cases**

## **Magnetic Shield Cases E989 Series**



Photomultiplier tubes are extremely sensitive to magnetic fields and exhibit output variations even from sources such as terrestrial magnetism. Hamamatsu E989 series magnetic shield cases are designed specifically to protect photomultiplier tubes from the influence of such magnetic fields. The E989 series uses permalloy, a material that has an extremely high permeability (approximately 10<sup>5</sup>). The magnetic field intensity within the shield case can be attenuated from 1/1000 to 1/10000 of that outside the shield case (this ratio is called the shielding factor). The E989 series ensures a stable output for photomultiplier tubes operating in proximity to magnetic fields.

## Features

- Made of high-permeability permalloy (Ni: 78 %, Fe and others: 22 %)
- Various sizes available with inner diameters from 12 mm to 138 mm
  Lusterless black paint finish

## Specifications

Photomultiplier Tube Diameter		Type No.	Internal Dia. D ( $\phi$ mm)	Thickness t (mm)	Length L (mm)	Weight (g)
Side-on	φ13 mm (1/2")	E989-10	$14.5\pm0.5$	0.5 +0.2	$47\pm0.5$	10
	φ28 mm (1-1/8") *	E989	$33.6\pm0.8$	0.8 +0.2	80 ± 1	66
Head-on	φ10 mm (3/8")	E989-28	$12\pm0.5$	0.5 +0.2	$48\pm0.5$	9
	φ13 mm (1/2")	E989-09	16 ± 0.5	0.8 +0.2	$75\pm0.5$	28
	φ19 mm (3/4")	E989-02	$23\pm0.5$	0.8 +0.2	95 ± 1	50
	¢25 mm (1")	E989-39	29 ± 0.5	0.8 +0.2	$48\pm0.5$	32
	<i>ϕ</i> 28 mm (1-1/8")	E989-03	32 ± 0.5	0.8 +0.2	120 ± 1	90
	∮38 mm (1-1/2")	E989-04	44-0	0.8 +0.2	100 ± 1	102
	∮51 mm (2")	E989-05	60 <sup>+1</sup>	0.8 +0.2	130 ± 1	180
	φ76 mm (3")	E989-15	80+1.5	0.8 +0.2	120 ± 1	170
	φ127 mm (5")	E989-26	138 ± 1.5	0.8 +0.2	170 ± 1	400

\* Photomultiplier tubes with HA treatment (see page 12) extending to the base portion cannot be used. Please consult our sales offices for details.

