

realized franker franker

CMOS linear image sensors

S10121 to S10124 series (-01)

Higher UV sensitivity than previous type, current-output type sensors with variable integration time function

The S10121 to S10124 series are self-scanning photodiode arrays designed specifically as detectors for spectroscopy. The scanning circuit operates at low power consumption and is easy to handle. Each photodiode has a large photosensitive area with high sensitivity and smoothly varying spectral response characteristics in UV region.

Features

Applications

Spectrophotometry

- High UV sensitivity
- High UV sensitivity than previous type
- Smoothly varying spectral response characteristics in UV region
- Variable integration time for each pixel
- Wide photosensitive area Pixel pitch: 50 μm, 25 μm Pixel height: 2.5 mm, 0.5 mm
- Large saturation output charge

Structure

Type no.	Number of pixels	Pixel pitch (µm)	Pixel height (mm)	Package	Window material *1 *2	Weight (g)
S10121-128Q-01	128	- 50 - 25	2.5	Ceramic	Quartz (t=0.5 mm)	3.0
S10121-256Q-01	256					5.0
S10121-512Q-01	512					3.5
S10122-128Q-01	128		0.5			3.0
S10122-256Q-01	256					5.0
S10122-512Q-01	512					3.5
S10123-256Q-01	256			Ceramic		3.0
S10123-512Q-01	512		0.5			5.0
S10123-1024Q-01	1024					3.5
S10124-256Q-01	256					3.0
S10124-512Q-01	512		2.5			5.0
S10124-1024Q-01	1024					3.5

*1: Resin sealing

*2: Refractive index=1.46

1

Absolute maximum ratings

Parameter	Symbol	Condition	Value	Unit
Supply voltage	Vdd	Ta=25 °C	-0.3 to +6	V
Clock pulse voltage	V(CLK)	Ta=25 °C	-0.3 to +6	V
Start pulse voltage	V(ST)	Ta=25 °C	-0.3 to +6	V
Integration time control pulse	V(INT)	Ta=25 °C	-0.3 to +6	V
Overflow gate voltage	Vofg	Ta=25 °C	-0.3 to +6	V
Overflow drain voltage	Vofd	Ta=25 °C	-0.3 to +6	V
Operating temperature	Topr	No dew condensation*3	-5 to +65	°C
Storage temperature	Tstg	No dew condensation*3	-10 to +85	°C

*3: When there is a temperature difference between a product and the surrounding area in high humidity environment, dew condensation may occur on the product surface. Dew condensation on the product may cause deterioration in characteristics and reliability.

Note: Exceeding the absolute maximum ratings even momentarily may cause a drop in product quality. Always be sure to use the product within the absolute maximum ratings.

Parameter	Symbol	Min.	Тур.	Max.	Unit		
Supply voltage	Vdd	4.75	5	5.25	V		
Clask pulsa valtaga	High level	V(CLK)	Vdd - 0.25	Vdd	Vdd + 0.25	- V V	
Clock pulse voltage	Low level	V(CLK)	0	-	0.4		
Start pulse voltage	High level	V(ST)	Vdd - 0.25	Vdd	Vdd + 0.25		
Start pulse voltage	Low level	V(ST)	0	-	0.4		
Integration time control pulse High le		V(INT)	Vdd - 0.25	Vdd	Vdd + 0.25	V	
voltage Low level		V(1NT)	0	-	0.4	v	
Overflow drain voltage		Vofd	0.5	2	2.5	V	
Overflow gate voltage		Vofg	0.17	0.2	0.23	V	

Recommended terminal voltage (Ta=25 °C)



	Parameter	Symbol	Min.	Тур.	Max.	Unit
Clock pulse	S10121/S10124 series	f(CLK)	10 k	-	250 k	Hz
frequency	S10122/S10123 series		10 k	-	500 k	
Video data rate		VR	-	f(CLK)	-	Hz
	S10121-128Q-01		-	0.75	-	
	S10121-256Q-01		-	1.75	-	
	S10121-512Q-01		-	4.25	-]
	S10122-128Q-01		-	1.5	-]
	S10122-256Q-01		-	3.5	-]
Power	S10122-512Q-01	Р	-	8.25	-	mW
consumption*4	S10123-256Q-01		-	3.25	-	
	S10123-512Q-01		-	7.25	-	
	S10123-1024Q-01		-	18.25	-	
	S10124-256Q-01		-	1.75	-	
	S10124-512Q-01		-	3.75	-	
	S10124-1024Q-01		-	8.25	-	
	S10121-128Q-01		-	10	-	- pF
	S10122-128Q-01					
	S10121-256Q-01		-	14	-	
	S10122-256Q-01					
Video line	S10121-512Q-01		-	22	-	
capacitance (Vb=2 V)* ⁵	S10122-512Q-01	- Cv				
	S10123-256Q-01	Cv	-	13	-	
	S10124-256Q-01					
	S10123-512Q-01		-	19	-	
	S10124-512Q-01					
	S10123-1024Q-01		_	32	_	
	S10124-1024Q-01			52	_	

Electrical characteristics [Ta=25 °C, Vdd=5 V, Vb=Vofd=2 V, Vofg=0.2 V]

*4: f(CLK)=250 kHz (S10121/S10124 series), 500 kHz (S10122/S10123 series)

*5: Vb is the voltage at the non-inverting input terminal of the charge amplifier in the current-integration readout circuit. [See the readout circuit example (p.8).]

Electrical and optical characteristics [Ta=25 °C, Vdd=5 V, Vb=Vofd=2 V, Vofg=0.2 V, f(CLK)=200 kHz]

Parameter		Symbol	Min.	Тур.	Max.	Unit
Spectral response range		λ		nm		
Peak sensitivity wavelength		λр	- 750 -		-	nm
	S10121 series	- ID	-	0.1	0.6	рА
Dark current	S10122 series		-	0.02	0.12	
Dark current	S10123 series		-	0.02	0.12	
	S10124 series		-	0.1	0.6	
Saturation output charge	S10121 series	- Qsat	110	165	-	
	S10122 series		22	32	-	
	S10123 series		11	14	-	pC
	S10124 series		55	75	-	
Saturation exposure*6		Esat	-	580	-	mlx · s
Photo response non-uniformity*6 *7 *8		PRNU	-	-	±3	%

*6: Measured with a tungsten lamp of 2856 K


*7: Photo response non-uniformity is defined under the condition that the device is uniformly illuminated by light which is 50 % of the saturation exposure level as follows:

 $PRNU = \Delta X/X \times 100 (\%)$


X: the average output of all pixels, ΔX : difference between X and maximum or minimum output.

*8: Except for the first and last pixels






Spectral response (typical example)




Spectral response in UV region (typical example)

Photosensitivity variation in UV region (typical example)




Photosensitivity in the UV region may slightly vary from product to product.

Block diagram











Output waveform of one pixel (S10124-1024Q-01)





Timing chart



Allow CLK pulse transition from "high" to "low" only one time while ST pulse is "high". Integration time is determined by the interval between start pulses.

Only the switching noise component is output from the Dummy Video line. Do not use the Dummy Video output during current-integration readout. The INT signal is not needed between EOS and the rising edge of the next ST signal.


KMPDC0249ED


Parameter		Symbol	Min.	Тур.	Max.	Unit	
Start pulse (ST) interval	S1012*-128Q-01		130/f(CLK)	-	-		
	S1012*-256Q-01	toi(CT)	258/f(CLK)	-	-	S	
	S1012*-512Q-01	tpi(ST)	514/f(CLK)	-	-		
	S1012*-1024Q-01		1026/f(CLK)	-	-		
INT pulse rise and fall times		tr(INT), tf(INT)	0	20	30	ns	
INT pulse - clock pulse timing		t(INT-CLK)	30	-	1 / [2 × f(CLK)]	ns	
Clock pulse - INT pulse timing		t(CLK-INT)	30	-	1 / [2 × f(CLK)]	ns	
Start pulse rise and fall times		tf(ST), tr(ST)	0	20	30	ns	
Clock pulse duty ratio		-	40	50	60	%	
Clock pulse rise and fall times		tf(CLK), tr(CLK)	0	20	30	ns	
Clock pulse - start pulse timing		t(CLK-ST)	20	-	-	ns	
Start pulse - clock pulse timing		T(ST-CLK)	20	-	-	ns	



Current-integration readout circuit example and timing chart example


Readout circuit example





* Supply the Vb terminal with the same voltage as Vofd.

KMPDC0562EA






Variable integration time function

By controlling the clock pulse to the INT terminal, the integration time for each pixel can be changed to any length that is an integer multiple of one readout period. When the clock pulse at the INT terminal is set to "high" at the pixel signal readout timing, then no signal is output from that pixel (see below). This allows the signal charge to continuously accumulate in that pixel as long as no signal is output. For example, when the integration time of one readout period is 100 ms and this function is used to output a signal from a pixel once every 3 readout periods, then the integration time of that pixel will be 300 ms. Using this function to lengthen the integration time of certain pixels makes it possible to effectively detect spectral signals of weak wavelength components.


■Timing chart

(Concept view showing the settings to double, triple and quadruple the integration times at channels 2, 3 and 4, respectively, by using the variable integration time function on the basis of the integration time at channel 1.)





Dimensional outlines (unit: mm)




- *2: Distance from the bottom of the package to the photosensitive surface
- *3: Window thickness


HAMAMATSU PHOTON IS OUR BUSINESS

 25.4 ± 0.13

KMPDA0061EG







Angle accuracy of effective pixels: ±2° Lead treatment: Ni/Au plating

- Lead material: FeNi alloy *1: Distance from the upper surface of the quartz window to the photosensitive surface
- *2: Distance from the bottom of the package to the photosensitive surface
- *3: Window thickness

KMPDA0217EG




0.51 ± 0.05

2.54 ± 0.13

 25.4 ± 0.13

 5.0 ± 0.5

Pin connections



Precautions during use

(1) Electrostatic countermeasures

This device has a built-in protection circuit against static electrical charges. However, to prevent destroying the device with electrostatic charges, take countermeasures such as grounding yourself, the workbench and tools to prevent static discharges. Also protect this device from surge voltages which might be caused by peripheral equipment.

(2) Incident window

If dust or dirt gets on the light incident window, it will show up as black blemishes on the image. When cleaning, avoid rubbing the window surface with dry cloth or dry cotton swab, since doing so may generate static electricity. Use soft cloth, paper or a cotton swab moistened with alcohol to wipe dust and dirt off the window surface. Then blow compressed air onto the window surface so that no spot or stain remains.

(3) Soldering

To prevent damaging the device during soldering, take precautions to prevent excessive soldering temperatures and times. Soldering should be performed within 5 seconds at a soldering temperature below 260 °C.

(4) Operating and storage environments

Always observe the rated temperature range when handling the device. Operating or storing the device at an excessively high temperature and humidity may cause variations in performance characteristics and must be avoided.

(5) UV exposure

This device is designed to suppress performance deterioration due to UV exposure. Even so, avoid unnecessary UV exposure to the device. Also, be careful not to allow UV light to strike the cemented portion of the glass.



Related information

www.hamamatsu.com/sp/ssd/doc_en.html

- Precautions
- · Disclaimer
- · Image sensors

Information described in this material is current as of October, 2015.

Product specifications are subject to change without prior notice due to improvements or other reasons. This document has been carefully prepared and the information contained is believed to be accurate. In rare cases, however, there may be inaccuracies such as text errors. Before using these products, always contact us for the delivery specification sheet to check the latest specifications.

The product warranty is valid for one year after delivery and is limited to product repair or replacement for defects discovered and reported to us within that one year period. However, even if within the warranty period we accept absolutely no liability for any loss caused by natural disasters or improper product use. Copying or reprinting the contents described in this material in whole or in part is prohibited without our prior permission.



www.hamamatsu.com

HAMAMATSU PHOTONICS K.K., Solid State Division

1126-1 Ichino-cho, Higashi-ku, Hamamatsu City, 435-8558 Japan, Telephone: (81) 53-434-3311, Fax: (81) 53-434-5184

U.S.A.: Hamamatsu Corporation: 360 Foothill Road, Bridgewater, N.J.08807, Telephone: (1) 908-231-108 Germany: Hamamatsu Photonics Deutschland GmbH: Arzbergerstr. 10, D-82211 Herrsching am Ammersee, Germany, Telephone: (49) 8152-375-0, Fax: (49) 8152-265-8 France: Hamamatsu Photonics Rance S.A.R.L.: 19, Rue du Saule Trapu, Parc du Moulin de Massy, 91882 Massy Cedex, France, Telephone: (3) 08-237-10 (b) 53 71 10 United Kingdom: Hamamatsu Photonics IV Limited: 2 Howard Court, 10 Tewin Road, Welwyn Grarden City, Hertfordshire A/T 18W, United Kingdom: Telephone: (41) 1707-294888, Fax: (44) 1707-325777 North Europe: Hamamatsu Photonics Norden AB: Torshamnsgatan 35 10440 Kista, Sweden, Telephone: (46) 8-509-031-01

Italy: Hamamatsu Photonics Italia S.r.l.: Strada della Moia, 1 int. 6, 20020 Arese (Milano), Italy, Telephone: (39) 02-93581733, Fax: (39) 02-93581741 China: Hamamatsu Photonics (China) Co., Ltd.: B1201, Jiaming Center, No.27 Dongsanhuan Beilu, Chaoyang District, Beijing 100020, China, Telephone: (86) 10-6586-6006, Fax: (86) 10-6586-2866